



D1000 / D1010 Series Quick Start Guide



- 1 Getting started
- 2 Using the phone
- 3 Help

This Quick Start Guide provides all the information you need to get you started. If you need more detailed instructions, a full user guide is available to download in PDF format from:

www.motorola.com/cordless-phones

Please consider the environment before printing.

Digital cordless phone **D1000**
Digital cordless phone with answering machine **D1010**



Box Contents





D1001/D1011 handset



D1001 base or D1011 base



2 x AAA NiMH rechargeable batteries



Screws and wall plugs for wall mounting



Quick Start Guide

If you have purchased a multiple pack you will also have the following additional items:

D1002/D1012

- 1 x Additional handset and charger
- 2 x AAA NiMH rechargeable batteries
- 1 x Mains power adaptor for charger with red connector.

D1003/D1013

- 2 x Additional handsets and chargers
- 4 x AAA NiMH rechargeable batteries
- 2 x Mains power adaptors for charger with red connector.

D1004/D1014

- 3 x Additional handsets and chargers
- 6 x AAA NiMH rechargeable batteries
- 3 x Mains power adaptors for charger with red connector.

Important

Only use the telephone line cord supplied. This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.


Warning!

Use only rechargeable batteries.

Getting started

Step 1. Set up the base


- Plug the mains power cable (with a clear connector) into the socket marked on the underside of the base and plug the other end into the mains power wall socket.



- Switch on the power supply

Tip

Position the base at least 1 metre away from other electrical appliances to avoid interference. Putting it as high as possible ensures the best signal.



Important

The base station must be plugged into the mains power at all times. Do not connect the telephone line cord into the wall socket until the handset is fully charged. Only use the power and telephone cables supplied with the product.

Step 2. Connect the charger (Multi-pack only)

- Plug the mains power cable (with a red colour connector) into the socket marked on the underside of the charger and plug the other end into the mains power wall socket.

- Switch on the power supply.

Getting started


Step 3. Charge the handset

- Insert the 2 x AAA NiMH batteries supplied into the handset and slide the battery compartment into place.
- Place the handset on the charger and charge for at least 24 hours. When the handset is fully charged, the icon is displayed.

- When the handset is fully charged, plug the telephone line cord into the socket marked on the underside of the base and plug the other end into the telephone wall socket.

Warning!

Use only rechargeable batteries. If non-rechargeable batteries are used **WARNING BATT** will be displayed and charging will be stopped. Please replace with rechargeable batteries.



Step 4. Select country

- After charging your phone, the Welcome screen appears.
- **WELCOME** is displayed and scrolls in different languages.
- Press . A list of countries is shown on the display.
- Scroll or to your country and press .
- Press to confirm.

The handset and base will be reset to load the correct settings and the standby screen is displayed.

Step 5. Set Date and Time

- Press and scroll to **CLOCK/ALARM**.
- Press . Display shows **DATE & TIME**, then press .
- Enter the date using the format **DD/MM**.
- Press and enter the time using the 24 hour format **HH:MM**.
- Press to confirm.

NOTE

If you have subscribed to your network's Caller Display service, the date and time is set automatically for all handsets every time a call is received.

Your phone is now ready for use.

Handset

Earpiece

Display

Menu key
Enter the main menu.
Select the option displayed on screen.
Confirm menu option - OK is displayed on screen.

Talk / Recall
Make or answer calls
Use recall (R) functions

Navigator glow ring
Illuminates when the phone is in use. Flashes to indicate new event, eg. missed call.

*** / Keypad Lock**
Press and hold to lock/unlock the keypad.
During a call, press and hold to switch from pulse dialling to tone dialling.
Dial a star

Handsfree key
Activate and deactivate the loudspeaker during a call.

Intercom (at least 2 handsets needed)
In standby mode, use to make an internal call.
During a call, use to transfer an external call to another handset.

Call Log / Scroll up / Volume up
Open the calls log.
Scroll up through lists and settings.
Increase the earpiece volume during a call.

Redial / Scroll right / Clear / Mute
Open the redial list. Scroll to the right.
Delete characters on screen when entering names and numbers.
Mute/unmute the microphone during a call.
Go back to previous menu level BACK is displayed.

Phonebook / Scroll down / Volume down
Open the phonebook.
Scroll down through lists and menus.
Decrease the earpiece volume.

End / Exit / Switch handset on/off End a call.
When in a menu, go back to standby mode.
Press and hold to switch handset off (when in standby) or on.

/ Ringer Off / Pause
Press and hold to switch handset ringer on and off.
When dialling or storing a number, press and hold to enter a pause (P).
Dial a #.

Display icons


- On when the line is in use. Flashes when there is an incoming call.
- Flashes when you have new voicemail messages. Off when you have no voicemail messages.
- Flashes when you have missed calls and new number(s) in the Calls list.
- Phonebook is open.
- The alarm clock has been set.
- Handsfree mode.
- Handset ringer is off.
- Answering machine On. Off when answering machine is off. Flashes when you have new messages. Flashes fast when the memory is full. (For D1010 series only)
- Steady when the handset is registered and within range of the base. Flashes when the handset is out of range or searching for base.

The approximate power levels of your battery are indicated as below:


- Battery is fully charged.
- Battery is partially charged.
- Battery is running low.
- Flashes when battery is almost discharged. The handset will emit a warning beep during a call every 60 seconds.

Using the phone

Make a call

- Enter the phone number and press .



Answer a call

- When the phone rings, press .


End a call

- Press .





Adjust earpiece volume

- During a call, press  or .




Redial last number

- Press  on the handset, then press .

Change the ringer volume and ringtone




- Press , scroll  to **PERSONAL SET** and press .
- HANSET TONE** is displayed, press .

- RING VOLUME** is displayed, press .

- Press  or  to adjust the ringer volume level and press  to save the setting.

- Scroll  to **RING MELODY**.

- Press .


- Scroll  or  to select your ring melody and press  to save the setting.


Add entry to phonebook




- Press , **PHONEBOOK** is displayed.

- Press , **NEW ENTRY** is displayed.




- Press , **ENTER NAME** is displayed.

- Enter a name and press .

- Enter a number and press .


- Scroll  or  to select a group melody and press , to save.


Dial from the phonebook

- Press  then scroll  or  to the entry you want to dial.

- Press .


Paging/Find handset

- Press  on the base. All handset registered to the base will ring.


- Press  again to stop ringing or press any key on the handset to stop the paging call.

For D1010 series only


Switch the answering machine on / off

- Press  at the base. When the base is switched on the LED is illuminated.

Listen to messages

- Press  at the base to play messages.

To operate your answering machine from the handset and base or by remote access from another phone, see the main user guide.



General information

Important

This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.

This product is intended for connection to analogue public switched telephone networks and private switchboards in EU.

Safety and Electromagnetic Interference/Compatibility information

- Only use the power supply suitable for this product range. Using an unauthorised power supply will invalidate your guarantee and may damage the telephone.
- Use only the approved rechargeable batteries supplied.
- Do not open the handset (except to replace the handset batteries) or the base. This could expose you to high voltages or other risks.
- Radio signal transmitted between the handset and base may cause interference to hearing aids.
- Your product may interfere with other electrical equipment, e.g. TV and radio sets, clock/alarms and computers if placed too close. It is recommended that you place your product at least one metre away from such appliances to minimise any risk of interference.
- All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewellery, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.
- Never dispose of batteries in a fire. There is a serious risk of explosion and/or the release of highly toxic chemicals.
- It is recommended that advice from a qualified expert be sought before using this product in the vicinity of emergency/intensive care medical equipment.
- Medical Devices
 - Pacemakers**: The Advanced Medical Technology Association (AdvaMed) recommends that a minimum separation of 15 cms (6 inches) be maintained between a handheld wireless device and a pacemaker. These recommendations are consistent with those of the U.S. Food and Drug Administration.
 - Persons with pacemakers should:** - ALWAYS keep the handheld wireless device more than 15 cms from their pacemaker when the handheld wireless device is turned ON.
 - Not carry the handheld wireless device in the breast pocket.
 - Use the ear opposite the pacemaker to minimize the potential for interference.
 - Turn the handheld wireless device OFF immediately if you have any reason to suspect that interference is taking place.
 - Hearing Aids** Some digital wireless radios may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to

discuss alternatives.

- Other Medical Devices** If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Cleaning

- Clean the handset and base (or charger) with a damp (not wet) cloth, or an anti-static wipe.
- Never use household polish as this will damage the product. Never use a dry cloth as this may cause a static shock.

Environmental

- Do not expose to direct sunlight.
- The handset may become warm when the batteries are being charged or during prolonged periods of use. This is normal. However, we recommend that to avoid damage you do not place the product on antique/veneered wood.
- Do not stand your product on carpets or other surfaces which generate fibres, or place it in locations preventing the free flow of air over its surfaces.
- Do not submerge any part of your product in water and do not use it in damp or humid conditions, such as bathrooms.
- Do not expose your product to fire, explosive or other hazardous conditions.
- There is a slight chance your phone could be damaged by an electrical storm. We recommend that you unplug the power and telephone line cord during an electrical storm.

Product disposal instructions

- European Union (EU) Waste of Electrical and Electronic Equipment (WEEE) directive. The European Union's WEEE directive requires that products sold into EU countries must have the crossed out trashbin label on the product (or the package in some cases). As defined by the WEEE directive, this cross-out trashbin label means that customers and end-users in EU countries should not dispose of electronic and electrical equipment or accessories in household waste. Customers or end-users in EU countries should contact their local equipment supplier representative or service centre for information about the waste collection system in their country.
- The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimize the impact on the environment, treat any hazardous substances and avoid the increasing landfill.

Product disposal instructions for residential users

When you have no further use for it, please remove any batteries and dispose of them and the

Help

For more solutions, see the full Help section in the main guide.

The icon is not scrolling when the handset is placed on the base

- Bad battery contact – move the handset slightly

- Dirty contact – clean the battery contact with a cloth moistened with alcohol

- Battery is full – no need to charge

- Use only rechargeable batteries. If non-rechargeable batteries are used **WARNING BATT** will be displayed and charging will be stopped. Please replace with rechargeable batteries.

No dialling tone

- Check the connections. Unplug your phone then plug back in the mains power.

- Batteries are empty - charge the batteries for at least 24 hours.

- You may be too far from the base - move closer.

- Use the line cable provided.

Poor sound quality

- Move closer to the base.

- Move the base at least one metre away from any electrical appliances.

The icon is blinking


- Move closer to the base.

- Register the handset to the base.

Caller Line Identification does not work

- Check your subscription with your network operator.

No ring tone

- If the  icon is displayed, the ringer is switched off. Increase the ringer volume.

- For details, see the main guide.

No display

- Try recharging or replacing the batteries.

- If LED is not lit up, then try disconnecting and connecting the base power supply. (For D1010 series only)**

Wall Mounting

- Please refer to the user guide for wall mounting template.

Need more help?

- For a full explanation of all features and instructions, please refer to the main user guide online at:

www.motorola.com/cordless-phones

product per your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

Product disposal instructions for business users

Business users should contact their suppliers and check the terms and conditions of the purchase contract and ensure that this product is not mixed with other commercial waste for disposal.

Warranty Information

The authorized Motorola dealer or retailer where you purchased your Motorola product will honour a warranty claim and/or provide warranty service. Please return your cordless telephone to your dealer or retailer to claim your warranty service. Do not return your telephone to Motorola. In order to be eligible to receive warranty service, you must present your receipt of purchase or a comparable substitute proof of purchase bearing the date of purchase. The telephone should also clearly display the serial number. The warranty will not apply if the type or serial numbers on the product have been altered, deleted, removed, or made illegible.

What Is Not Covered By The Warranty

- Defects or damage resulting from use of the Product in other than its normal and customary manner or by not following the instructions in this user manual.
- Defects or damage from misuse, accident or neglect.
- Defects of damage from improper testing, operation, maintenance, adjustment, or any alteration or modification of any kind.
- Breakage or damage to aeriels unless caused directly by defects in material or workmanship.
- Products disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection and testing to verify any warranty claim.
- Defects or damage due to moisture, liquid or spills.
- All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal use.
- Periodic maintenance and repair or replacement of parts due to normal usage, wear and tear.

Technical Information

How many telephones can I have?

All items of telephone equipment have a Ringer Equivalence Number (REN), which is used to calculate the number of items which may be connected to any one telephone line. Your D1001 / D1011 has a REN of 1. A total REN of 4 is allowed. If the total REN of 4 is exceeded, the telephones may not ring. With different telephone types there is no guarantee of ringing, even

when the REN is less than 4. Any additional handsets and chargers that you register have a REN of 0.

R&TTE

This product is intended for use within EU for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC including compliance with ICNIRP standard for electromagnetic energy exposure.

Declaration of Conformance

Hereby, Motorola declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The Declaration of Conformance for this product range is published on the website:

<http://www.motorola.com/rtte>

Connecting to a switchboard

This product is intended for use within EU for connection to the public telephone network and compatible switchboard.

Inserting a pause

With some switchboards, after dialling the access code you may have to wait for a moment while the switchboard picks up an outside line so you will need to enter a pause in the dialing sequence.

Press and hold # to insert a pause (P) before entering the telephone number. You may also need to enter a pause when storing international numbers or charge card numbers.

Recall

You may need to use the recall function if you are connected to a switchboard/PBX (Private Branch Exchange), contact your PBX supplier for further information.



MOTOROLA, the Stylized M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. © Reg. U.S. Pat. & Tm. Off. © Motorola, Inc. 2008

Printed in PRC
Part number 6864527V01
EN version 1.2