

Press the PHONE/OK button, the display shows "BS VOLUME"
 Press the PHONE/OK button, the display shows "VOLUME2"
 Use the UP/DOWN button to adjust volume. There are three levels.

Press the PHONE/OK button to confirm
 Press and hold the HANG UP/C button to go back to idle mode

Change base ringer melody
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "BS RINGER"
 Press the PHONE/OK button, then
 Press the DOWN button to select "BS MELODY"
 Press the PHONE/OK button, the display shows "MELODY 1"
 Use the UP/DOWN button to change the melody. There are 3 options.
 Press the PHONE/OK button to confirm
 Press and hold the HANG UP/C button to go back to idle mode

Using a multi-handset system

Make intercom calls
 Press the INTERCOM button on any handset (i.e. handset 1).
 The intercom icon INT will appear, e.g. "INT 2".
 Use the digit buttons to press the handset number 2 you want to call, and the display shows e.g. "CALL INT 2".
 Handset 2 will ring
 On the handset being called, press the PHONE/OK button to answer and the intercom icon 'INT' will appear on the display e.g. "INT 1"
 Press the HANG UP/C button to end the call

Transfer intercom calls
 When one handset is on an external call and wants to transfer the call to another handset
 Press the INTERCOM button on the handset on the external call (i.e. handset 1)
 The intercom icon INT would appear e.g. "INT 2"
 Use the digit buttons to press the handset number you want to transfer the call to (the external line will be on-hold at this moment) Handset 2 will ring
 Press PHONE/OK of handset 2 to answer the intercom call
 Press HANG UP/C button on handset 1 to transfer the call to handset 2

Shuttle between two calls
 When an external call and an intercom call are in progress at the same time you can shuttle between the two calls by pressing the INTERCOM button on your handset.

Set up a three-way conference
 You can have a three-way conference when you are on a call with an external line
 When you are on the phone press the INT button
 Press the handset number you want to join the conference. Handset 2 will ring
 Press PHONE/OK to answer intercom call
 Press and hold * key to enter conference

11

Guarantee and service
 The Binatone Style1200/1210 is guaranteed for 12 months from the date of purchase shown on your sales receipt. This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, faults on the telephone line, lightning, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.
Please keep your sales (bill) receipt – this is your guarantee. You should also keep the original packaging material.
 In the unlikely event that you need to return your Style1200/1210 to our Repair Centre while it is under guarantee, there will be a £5 handling charge.

While the unit is under Guarantee

1. Disconnect the base unit from the telephone line and the mains electricity supply
2. Pack up all parts of your Style1200/1210, using the original packaging. Remember to include the mains adapter
3. Return the unit to the shop where you bought it, making sure you take your sales receipt.

After the Guarantee has expired
 If the unit is no longer under Guarantee, first follow steps 1 and 2 as for repair under Guarantee. Then...
 3. Call our Service Department on **0845 345 9677** and ask for a quotation of the repair charge and details of where to send your Style1200/1210 for repair.
 4. Make sure you include with your Style1200/1210:
 Your name and address
 A cheque or postal order for the value of the repair charge
 5. Return your Style1200/1210 to the address given by the Service Department.
 * This does not affect your statutory rights.

Technical details

Standard Digital Enhancement Cordless Telecommunication (DECT)
Frequency range 1.88 to 1.9 GHz (bandwidth = 20 MHz)
Channel bandwidth 1.728 MHz
Operating range Up to 300m outdoors; up to 50m indoors
Operating time Standby: 80 hours
 Talking: 8 hours
 Battery charge time: 15 hours

Temperature range Operating 0 °C to 40 °C
 Storage -20 °C to 60 °C

Electrical power HANDSET – 300mAH NiMH rechargeable battery pack.
 Base UNIT/CHARGER POD – input 230V 50Hz 30mA; output DC7.5 300mA 2.25VA
Port specification
 The port (connected to the telephone line) is a TNV port with respect to EN41003.

UK (BTP) Ver 2, June 07

18

Style 1200/1210 Stylish Digital Cordless Telephone

USER GUIDE

Digital Cordless Telephone with Caller Display, Name and Number Phonebook and Answering Machine (Style 1210 only).



Unpacking your phone
 In the box you will find:
 • the **cordless handset** (two handsets with a Twin system, three with a Triple system and four with a Quad system)
 • the **base unit**, with attached mains power lead and adapter
 • **rechargeable batteries** and a **battery compartment cover for each handset**
 • a **telephone line cable** for the base unit
 • **charger pods**, each with an attached mains power lead and adapter, for multi-handset system

**** Keep your sales receipt as it is your guarantee**

Binatone

Binatone Helpline (for UK only)
 Monday to Friday from 9:00am to 5:00pm
 Tel: 0845 345 9677
 **Please note that all calls are charged at local rate

Or visit our website: www.binatoneonline.com

Charging batteries for the first time
 Before you start to use your telephone make sure that all batteries are fully charged for 15 hours.

Important note: This telephone is not designed for Emergency calls when the main power fails
 For Emergency calls you should have a basic phone that does not need a mains power, connected to your line so that you can make calls during a power failure.

1

New call tone
 When there is an external call during your intercom call, a new call tone will be heard.
 Press the R button to answer the external

Paging handset
 The paging function is useful when you need to locate your handset(s).
 On the underside of the base set you will find the HANDSET LOCATOR button.
 Press the HANDSET LOCATOR button and your handset(s) will ring
 Press PHONE/OK button to stop it ringing.

Handset registration

* When you purchase a Style1200/1210 multi-handset system, all handsets are already registered: you do not need to register any of the handsets.
 * Handset registration is only necessary when you buy an extra-handset by itself.
 * Up to 4 handsets can be registered to your Style1200/1210 base.
 * Each handset can be registered to up to 4 base units.

Registering a handset
 Press the **HANDSET LOCATOR** button at the base station until you hear the registration tone (continuous beeps). The base station will stay in registration mode for 60 seconds.
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button six times, the display shows "REGISTER"
 Press the PHONE/OK button "BS 1234" (234 will flash)
 * Flashing numbers indicate base registrations not used
 Select your base using the digit buttons, e.g. press 1 for BASE 1.
 Enter the PIN using the digit buttons (default PIN is 0000).
 Press PHONE/OK to confirm, the display shows "WAIT"
 Wait until the handset beeps and the free handset numbers are shown on the display (this may take a short while).
 Select the handset number you require using the corresponding digit button.
 There will be a double beep tone and the handset will return to idle mode with the new handset number shown.

De-registering a handset
 *This may be necessary if one of your handsets is lost or out of order and needs to be replaced.
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button seven times, the display shows "DEL H/S"
 Press the PHONE/OK button to confirm
 All the handset numbers registered to that base will appear on the display
 Enter the handset number you want to de-register
 Press and hold the HANG UP/C button to go back to idle mode
 * The handset that has been de-registered will show "UNREGISTER" on its display, if it is not registered to any other base.

12

Select a base unit
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "SEL BASE"
 Press the PHONE/OK button
 Select the base unit you want to register your handset to. The number not flashing is the base which is currently selected.
 (Select 0 = Auto mode to automatically link with the first available base)
 Press the PHONE/OK button to confirm. The handset will display "RANGE OUT" for a short while until it links with the new base.
 To register to a different brand of base unit.
 Your Style1200/1210 handset can be registered to any GAP-compatible base unit, or you can register other GAP compatible handsets to your Style1200/1210 base unit, but we do not guarantee that all features or display messages will be available when using other manufacturers' equipment.

Advanced use of your phone
Handset advanced settings

Auto-answer
 With auto-answer is turned on, you can answer an incoming call by simply lifting the handset from its place on the base unit or charger pod.
 To turn auto-answer on and off:
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "HANDSET"
 Press the PHONE/OK button, the display shows "H/S NAME"
 Press the DOWN button to select "AUTO ANS/(ON)
 Press PHONE/OK to turn off auto answer, the display shows "AUTO ANS X" (OFF)
 *Press PHONE/OK again to turn auto answer back on.
 Press and hold the HANG UP/C button to go back to idle mode

To clear handset phonebook and redial memories.
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "HANDSET"
 Press the PHONE/OK button, the display shows "H/S NAME"
 Press the DOWN button to select "CLEAR MEM"
 Press the PHONE/OK button, the display shows "CONFIRM?"
 Press the PHONE/OK button to clear or press the HANG UP/OK button to not clear the memories and then to return to idle mode

Set to Default Settings
 Set handset settings to default
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "HANDSET"
 Press the PHONE/OK button, the display shows "H/S NAME"

13

Press the DOWN button to select "DEFAULT"
 Press the PHONE/OK button, the display shows "CONFIRM ?"
 Press the PHONE/OK button to reset, the display shows "DEFAULT"
 Press and hold the HANG UP/C button to go back to idle mode

Set base settings to default
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "BASE"
 Press the PHONE/OK button, the display shows "PIN CODE"
 Press the DOWN button to select "DEFAULT"
 Press the PHONE/OK button, the display shows "CONFIRM ?"
 Press the PHONE/OK button to reset, the display shows "DEFAULT"
 Press and hold the HANG UP/C button to go back to idle mode

Change your pin code
 The PIN code is only used when registering new handsets to the base, see page 12.
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "BASE"
 Press the PHONE/OK button, the display shows "PIN CODE"
 If the current Pin code is not the default (0000) the display shows "PIN _ _ _ _".
 Then key in the current Pin code.
 (If the current Pin code is the default (0000), this step will be skipped.)
 Press the PHONE/OK button, the display shows "NEW _ _ _ _"
 Key in your new Pin code
 Press the PHONE/OK button to confirm, the display shows "NEW _ _ _ _"
 Key in the new pin code again
 Press the PHONE/OK button to confirm
 Press and hold the HANG UP/C button to go back to idle mode

Select Dialing Mode
 You should normally leave the dialing mode at its default setting of TONE (also called DTMF).
 To change the dialing mode if necessary.
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "BASE"
 Press the PHONE/OK button, the display shows "PIN CODE"
 Press the DOWN button once, the display shows "DIAL MODE"
 Press the PHONE/OK button, the display shows "TONE"
 Press the UP or DOWN button to change between TONE and PULSE
 Press the PHONE/OK button to confirm your selection, the display shows "DIAL MODE"
 Press and hold the HANG UP/C button to go back to idle mode
 Note: If PULSE dialing is set, you can press the * key to switch to TONE dialing for the rest of that call.

14

Set Flash time (Recall)
 You should not need to change the setting from the default of SHORT (100ms), unless you're having a problem with the Flash (Recall) when using your phone on a PBX.
 Press MENU button, the display shows "PHONEBOOK"
 Press the DOWN button to select "BASE"
 Press the PHONE/OK button "PIN CODE"
 Press the DOWN button twice, the display shows "FLASH"
 Press the PHONE/OK button, the display shows "SHORT"
 Press the DOWN button to select SHORT (100ms), MEDIUM (250ms) or LONG (600ms).
 Press PHONE/OK to confirm, the display shows "FLASH"
 Press and hold the HANG UP/C button to go back to idle mode

To turn Baby call ON/OFF:
 Press MENU button, the display shows "PHONEBOOK"
 Press the UP button to select, the display shows "BABYCALL"
 Press the PHONE/OK button, the display shows "ON/OFF" (X)
 Press the PHONE/OK button to select Baby call, the display shows ON (✓) or OFF (X)
 If you have selected to the ON(✓), press "✓" button and you can enter the number then press OK
 Press and hold the HANG UP/C button to go back to idle mode
 When Baby Call is turned on, the number is shown on the display, with a lock symbol

Troubleshooting
 ALWAYS check first that:
 You have followed all the steps listed on page 5 to install and set up your Style1200/1210
 All **connectors** are firmly inserted in their sockets
 Mains power to the base unit is switched on at the socket
 The handset's **batteries** are correctly and securely installed and are not run down
Everyday use
 If the handset's display is blank. It may be **switched off**. Press the **HANG UP** button to switch it back on.
 Check that the base unit's **mains power adapter** is plugged in and **power is switched on**. The base unit needs mains power for normal operation of the phone – not just for charging the batteries.
 Make sure you are using the **telephone line cable** supplied with your Style1200/1210. Other telephone line cables might not work.
 Move the handset **closer** to the base unit
 Check the **battery Level** symbol on the display. If it is low, replace the handset on the base unit or charger pod to recharge the batteries.
Baby Monitor may be turned on. You need to turn it **off** before you can make calls.
Switch off power at the mains socket, wait for a short time and then **switch back on**. This may solve the problem.

15

"I cannot make a call"
 The handset's keypad may be **locked**. Unlock it before you make a call.
 Only one handset (or the base unit) can be connected to the outside line at once. If another handset is already using the line, you need to wait until it's finished its call.

"When I press keys, nothing happens"
 Make sure the **batteries** are fitted in your handset. If the Battery Level symbol on the display shows 'low', put your handset back on the cradle for it to charge.

"When I key in a number, it appears on the display, but I can not make an outside call."
 Try a **different position** for the base unit – somewhere higher if possible, or further from other electrical equipment.
 Try moving the handset **closer** to the base unit.

"The phone does not ring"
 Check that the base unit's **mains power** adapter is plugged in and power is switched on. The base unit needs mains power for normal operation of the phone – not just for charging the batteries
 Make sure you are using the **telephone line cable** that was supplied with your Style1200/1210. Other telephone line cables might not work

"My call was cut off when I went out of range. Now I can't use my handset."
 Move the handset **closer** to the base unit before you try again to make a call.

"There is interference and noise on the line"
 Move the handset **closer** to the base unit, or to a different position.
 Try moving the base unit so that it's **not near other electrical equipment**, such as a television or a computer.
 You'll get the best sound if you place the base unit **as high as possible**. For example, in a two-storey house, the first-floor landing is an ideal place.

"I hear 'beeps' from my handset while I'm on a call"
 You may be going **out of range** of the base unit. Move closer or your call may be cut off.
 Check the **Battery Level** symbol on the display. If it's low, recharge the batteries.

"The Caller Display feature isn't working"
 You need to **subscribe** to the Caller Display feature from your network service provider. You should find contact details on your phone bill.
 The caller may have **withheld** their number by dialing 141. Or they may be calling from a network that does not transmit the caller's number (e.g. it may be an international call.)

"When I try to make a call, I hear Busy tone."
 If you're using a Style1200/1210 multi-handset system, check whether another handset is already on a call.

"The volume in the earpiece is low when I'm on a call"
 Make sure you're holding the earpiece correctly over your ear.
 Adjust the volume using the UP/DOWN button.

16

Intercom and transfer

"I can't transfer a call"
 Make sure the other handset is in range of the base unit.
 Make sure you are dialing the correct number for the other handset.

Batteries
 "The handset's battery pack is running low within an hour or two"
 Before you first use the handset, you should have left it on the base unit or charger pod for **15 hours** to charge the batteries fully.
 You may need to **replace the batteries**
Check the connection between the base unit and the mains power socket

"I try to recharge the batteries but I still get a warning that they are low"
 You need to **replace the batteries**. To find out how to obtain replacements call the **Binatone Spares Department on 0845 345 9677** from 9:00am to 5:00pm, Monday to Friday.
Dispose of used batteries safely – never burn them, or put them where they could get punctured.
Do not use non-rechargeable batteries in your Style1200/1210 – they may burst, causing damage.

If the fault persists...
Disconnect all other instruments connected to the same line as the Style1200/1210 and try to make a call
Disconnect the base unit from the telephone line and plug a different phone into the master telephone socket. Try making a call.
 If this works, the line is OK.
 If the call does not work, and you are using a **two-way socket adapter**, remove it and plug a telephone directly into the socket.
 If the call now works, the adapter may be faulty.
 If you cannot make a call, the fault may be on the **exchange line**. Contact the service provider (the BT engineers on 151, or your cable company).
 If you still cannot identify the cause of the problem, contact the **Binatone Help Line on 0845 345 9677**.

Cleaning and care
Do not clean any part of your Style1200/1210 with benzene, thinner or other solvent chemicals – this may cause permanent damage which is not covered by the Guarantee.
 When necessary, **clean it with a damp cloth**.
 Keep your Style1200/1210 away from **hot, humid conditions or strong sunlight**, and **don't let it get wet**.
 Every effort has been made to ensure high standards of reliability for your Style1200/1210. However, if something does go wrong, please **do not try to repair it yourself** – consult your supplier or the Binatone Help Line.

Declaration of conformity
 Binatone Style1200/1210 complies with the essential protective requirements and objectives of:
 EC R&TTE Directive 2006/95/EC
 And conforms to the following relevant harmonized standards:
 Radio: EN 301406 (TBR 6)
 EMC: EN 301489
 Safety: EN 60950, EN 41003

17