

## BigTel 201

Bedienungsanleitung

**User manual** 

Mode d'emploi




DE

GB

FR





## Connecting the charging station

Connect the charging station to a mains power outlet.

Attention: Use only the power adapter plug supplied with the charging station! You should ensure access to the power adapter plug is not obstructed by furniture or such.

## Registering the handset



Press the **Menu** key. Select Handset and press





the softkey under Select Register and press



the softkey under .



Select a number for the base station (1 - 4)

Enter the relevant PIN for the base

and press the softkey under The new handset prompts "Press & Hold Page



Kev On Base". Press and hold down the paging key on the base station until the LED is flashing (approx. 10 sec).

After a few seconds the handset will be registered.

## Menu Structure with a base BigTel 200/202

Phonebook		
Handset —	Ring Tone —	External Internal
	Ringer Volume	
	Handset Name	
	Keypad Beep	
	Contrast	
	Auto Talk	
	Backlight Time	
	Confirm Beep	
	Select Base	
	Language	
	Registration	
I	Boost On	
Base Settings	Ring Tone	
	Ringer Volume	
	Dial Mode ————	Tone / Pulse
	Recall ————	Short / Long
	System PIN	
Time —	Set Alarm	
	Date and Time	
	Set Time Format	
Tools —	Appointment	
	Stop Watch	

Detailed information for using the handset and instructions for safety and disposal you find in the user guide of your BigTel 200/202.

GB



Vertrieb: Audioline GmbH, D-41460 Neuss