

Wichtige Hinweise zu Headsets

Stand 29.10.2013

English version at page 3

Bitte wenden Sie sich bei Fragen zu passenden Headsets unbedingt direkt an den jeweiligen Headset-Hersteller bzw. an dessen Fachhandelspartner.

Die Tiptel.com GmbH kann keine Gewähr für die Richtigkeit der Unterlagen übernehmen.

Diese Unterlagen ersetzen nicht eine fachlich kompetente Beratung durch den Anbieter.

Änderungen und Modellwechsel vorbehalten.

Liste aller Tiptel-Produkte mit Headset-Unterstützung

Geräte, an denen lediglich ein Headset über die Hörschnittstelle (mit Umschalter) angeschlossen werden kann und der Hörer auch noch abgehoben und aufgelegt werden muss, sind nicht aufgeführt.

Die aufgeführten Geräte verfügen mindestens über eine Taste zur Gesprächsannahme bzw. zum Auflegen, entweder geschieht dies über die Freisprechtaste (gekennzeichnet mit FR) oder über eine eigene Headset-Taste (HT).

Geräte mit einer zusätzlichen DHSG-Schnittstelle (auch unter EHS bekannt) sind entsprechend gekennzeichnet.

Achtung: Der gleichzeitige Anschluß eines schnurgebundenes Headsets UND ein DHSG-Headsets an entsprechenden Geräten ist nicht möglich (auch wenn die Geräte zwei Buchsen besitzen).

Kategorie A

Telefone mit Anschluss eines Headsets über Umschalter Handset/Headset bzw. direkt an Stelle des Handsets (Westernbuchse 4P4C)

Belegung Siemens (spiegelverkehrt zur Standard-Belegung)

(HT): tiptel 290 ISDN

(HT): tiptel 291 ISDN/Mailbox

(HT): tiptel 292 ISDN/CTI

(HT): tiptel 293 ISDN/CTI/Mailbox

(HT): tiptel 83 System So

(HT): tiptel 83 System Upo

(HT): tiptel 2020

(HT): tiptel 2030

(FR): tiptel ergoVoice S

(FR): tiptel ergoVoice C

(FR): tiptel ergoVoice CR

(FR): tiptel Ergophone C

(FR): tiptel Ergophone CR

Kategorie B

Geräte mit Anschluss eines Headset über eigene Headsetbuchse Western 4P4C bzw. DHSG (Western 8P8C), wo aufgeführt.

Belegung Siemens (spiegelverkehrt zur Standard-Belegung)

(--): tiptel 570 (Profi-Anrufbeantworter), beim Einstecken eines Headsets werden Lautsprecher und Mikrofon automatisch abgeschaltet ("Stille Wiedergabe")

(FR): tiptel 160

(FR): tiptel 160iS

(HT): tiptel IP 280

(HT): tiptel IP 284 (DHSG nur mit optionalem Adapter EHS36)

(HT): tiptel IP 286 (DHSG nur mit optionalem Adapter EHS36)

(HT): tiptel 3110 (+DHSG-Buchse, Rufannahme/Auflegen auch am Funk-Headset möglich)

(HT): tiptel 3120 (+DHSG-Buchse, Rufannahme/Auflegen auch am Funk-Headset möglich)

(HT): tiptel 3130 (+DHSG-Buchse, Rufannahme/Auflegen auch am Funk-Headset möglich)

Kategorie C

Telefone mit Anschluss eines Headset über eigene Headsetbuchse Western 4P4C bzw DHSG (Western 8P8C), wo aufgeführt.

Belegung Standard

(HT): tiptel 83 VoIP

(HT): tiptel 85 System So (+DHSG-Buchse, Rufannahme/Auflegen am Funk-Headset oder am Gerät möglich)

(HT): tiptel 85 System Upo (+DHSG-Buchse, Rufannahme/Auflegen am Funk-Headset oder am Gerät möglich)

(FR): tiptel 275 (+DHSG-Buchse, Rufannahme/Auflegen am Funk-Headset, am Gerät nicht möglich, FR nur für konventionelle Headsets)

(FR): tiptel 274 (+DHSG-Buchse, Rufannahme/Auflegen am Funk-Headset, am Gerät nicht möglich, FR nur für konventionelle Headsets)

(FR): tiptel 272

(FR): tiptel 1010

(FR): tiptel 1020

Kategorie D

DECT-Telefone mit 2,5 mm - Klinkenbuchse

tiptel easyDECT XL2

tiptel ergoVoice XL3

tiptel DECT-Z 3040 (baugleich KIRK 3040)

tiptel DECT-Z 4040 (baugleich KIRK 4040)

Important hints for using headsets

29.10.2013

For any questions about suitable headsets, please address yourself directly to the particular manufacturer of the headset or to his partner from specialized trade. The Tiptel.com GmbH is not able to take guarantee for the correctness of the documents. These documents do not replace the professional advice by the supplier. Technical changes or changes of model are reserved.

List of all Tiptel products -supporting headsets

Devices, which can be merely connected to a headset by a handset interface (with a switch) and where the handset must be picked up and replaced, are not listed.

The listed devices have a key to start a conversation and to finish it, either by activating the hands-free key (identified as "FR") or by activating an own headset key ("HT").

Devices with an additional DHSG-interface (also known as "EHS") are identified accordingly.

Caution: The concurrent connection of a corded headset and that of a DHSG-headset to according machines is not possible (even if the machines have two sockets).

Category A

Telephones with connection to a headset by a switcher handset/headset or directly instead of the handset (western socket 4P4C)

Pin Assignment Siemens (mirror-inverted to the standard allocation)

(HT): tiptel 290 ISDN

(HT): tiptel 291 ISDN/Mailbox

(HT): tiptel 292 ISDN/CTI

(HT): tiptel 293 ISDN/CTI/Mailbox

(HT): tiptel 83 System So

(HT): tiptel 83 System Upo

(HT): tiptel 2020

(HT): tiptel 2030

(FR): tiptel ergoVoice S

(FR): tiptel ergoVoice C

(FR): tiptel ergoVoice CR

(FR): tiptel Ergophone C

(FR): tiptel Ergophone CR

Category B

Devices with connection to a headset using an own headset socket Western 4P4C and DHSG (Western 8P8C) if it is listed.

Pin Assignment Siemens (mirror-inverted to the standard allocation)

(--): tiptel 570 (answering machine for experts), when inserting a headset, loudspeaker and microphone are switched off automatically. ("silent playback")

(FR): tiptel 160

(FR): tiptel 160iS

(HT): tiptel IP 280

(HT): tiptel IP 284 (DHSG only with an optional adapter EHS36)

(HT): tiptel IP 286 (DHSG only with an optional adapter EHS36)

(HT): tiptel 3110 (+DHSG-socket, starting and finishing the conversation is also possible on the wireless headset.

(HT): tiptel 3120 (+DHSG-socket, starting and finishing the conversation is also possible on the wireless headset.

(HT): tiptel 3130 (+DHSG-socket, starting and finishing the conversation is also possible on the wireless headset.

Category C

Telephones with connection to a headset using an own headset socket Western 4P4C and DHSG (Western 8P8C) if it is listed.

Pin Assignment Standard

(HT): tiptel 83 VoIP

(HT): tiptel 85 system So (+DHSG-socket, starting and finishing the conversation possible on the wireless headset or on the device itself.

(HT): tiptel 85 System Upo (+DHSG-socket, starting and finishing the conversation possible on the funk headset or on the machine itself.

(FR): tiptel 275 (+DHSG-socket, starting and finishing the conversation possible on the wireless headset, not possible on the device itself, FR only available for conventional headsets)

(FR): tiptel 274 (+DHSG-socket, starting and finishing the conversation possible on the wireless headset, not possible on the device itself, FR only available for conventional headsets)

(FR): tiptel 272

(FR): tiptel 1010

(FR): tiptel 1020

Category D

DECT-telephones with a jack of 2,5 mm

tiptel easyDECT XL2

tiptel ergoVoice XL3

tiptel DECT-Z 3040 (identical with KIRK 3040)

tiptel DECT-Z 4040 (identical with KIRK 4040)