



# Polycom Documentation

Copyright © 2020, Polycom, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc  
6001 America Center Drive

San Jose, CA 95002

USA

# Poly CCX 400 Business Media Phone Hardware

---

The following figure displays the hardware features on Poly CCX 400 business media phones. The table lists each feature numbered in the figure.

Figure 1. Poly CCX 400 phone hardware features




Table 1. Poly CCX 400 Phone Hardware Feature Descriptions

Reference Number	Feature	Feature Description
1	Reversible tab	Secures the handset in the cradle when you position your phone stand at a high angle. To secure the handset, remove the tab, reverse it so the protrusion points up, and reinsert it. Position the handset so the protrusion on the tab fits into the slot on the handset.
2	Message waiting indicator	Flashes red to indicate when you have new messages.

Reference Number	Feature	Feature Description
3	Touchscreen	Enables you to select items and navigate menus on the touch-sensitive screen.
4, 5	Volume keys	Adjusts the volume of the handset, headset, speaker, and ringer.
6	USB port(s)	Enables you to attach a USB flash drive or USB headset.  CCX 400 phones contain one USB-A port.
7	Headset indicator	Displays when the phone is powered on. The icon glows green or blue when a headset is connected and activated.
8	Speakerphone indicator	Displays when the phone is powered on. The icon glows green when activated.
9	Speaker	Provides ringer and speakerphone audio output.
10	Mute key	Mutes local audio during calls and conferences.

### Related Topics

[CCX Phone Hardware Overview](#)