PROJECT TELECOM

UNIFYING COMMUNICATIONS

Advanced Noise Cancelling Wireless Bluetooth Headset

USER GUIDE

Specifications

Pairing Name: M800BTD

Bluetooth Specification:CSR8635. V4.1,dual mode, downward compatible.

Frequency Range: 2402-2480MHz

Modulation: GFSK, π/4 DQPSK, 8DPSK

Two Bluetooth devices can be connected at the same time.

Transmission Distance: up to 20 meters (Transmission distance varies depending on the environment and Bluetooth device)

Maximum Talk Time: 12 hours

Standby Time: 250 hours

Speaker:

Resistance: 32 ohms

Frequency: 20Hz-20KHz, Hi-fi

Sensitivity: 115dB±3dB

Distortion: ≦1%

Microphone:

Microphone: Noise Canceling

Sensitivity: -38dB±3dB

Crystal clear sound and voice (DSP)

Headset Battery:

Type: Lithium-ion polymer

Capacity:145mA per hour stand

Battery Capacity: 150mAh

Charging Voltage: 5V DC

Life Time: Minimum recharging 1000 times

Operating Temperature: -10℃ to +60℃

Charging Time: 2 hours

Charging interface: Micro USB

Charging Base

Size:74.7*74.7*52mm   Net Weight:105g

Net Weight:

M800BT Mono 46.5g   M800BT Duo 58.2g

LED Indicator
（Battery, Pairing,Call status）

Plus button
(Volume up,Next song,
Mic mute)

Multi-function button
(Answer, Hang up, Pause
and Play)

Minus button
(Volume down,Last song)

Noise canceling Microphone

On/Off button
(Power on,Power off)

Pairing with Bluetooth Device

1. Be sure that your smart phone, laptop or desk phone with Bluetooth function.
2. Activate the Bluetooth function on your smart phone, laptop or desk phone.
3. Turn on your headset (slide switch to icon " ❊ "), you can hear prompt tone" power on".
   The Led indicator will flash red and blue alternately, which indicates the headset is in
   pairing mode.
4. (If pairing fails, the headset will power off automatically after indicator flashes 5mins, with
prompt tone "power off" heard.)
5. Pair headset to your smart phone, laptop or desk phone.
   1) Search Bluetooth device on your smart phone, laptop or desk phone.
   2) Open "Bluetooth" menu and press "discover" or "add" to search M800BTon your
   smart phone, laptop or desk phone.
   3) When M800BT shows on your Bluetooth devices list, please click it to start pairing.
   Prompt tone "connect" will be heard when pairing is successful, and the LED indicator will
   repeatedly flash blue every 5 seconds.
   4) The second time to use this headset on your Bluetooth device, it will pair with your
   Bluetooth device automatically when turn on the headset and Bluetooth device.

Button Function:

Button	Function	Action
On/Off Button	Headset on	Slide switch to icon " ❊ "
	Headset off	Slide switch to icon "off"
Plus Button	Volume up	Tap the Plus button to increase the speaker volume
	Next song	Long press the Plus button to switch to next song when playing music
	Mic mute	Long press the Plus button for 2 seconds to activate mic mute during a call, repress the Plus button for 2 seconds to cancel mic mute.
Minus Button	Volume down	Tap the Minus button to decrease the speaker volume
	Last song	Long press the Minus button to switch to last song when playing music
Multi-function Button	Pause	Tap the Multi-function button when playing music
	Answer /end call	Tap the Multi-function button
	Reject call	Long press the Multi-function button for 2 seconds.

Headset LED Indicators

Headset Status	LED Status
Pairing Mode	Light flashes blue and red alternately
Pairing Successfully	Light flashes blue repeatedly every 5 seconds
Battery Low	Light flashes red continuously
Charging Mode	Red light continuously on
Fully Charged	Blue light continuously on

Prompt Tone Introduction

Headset Status	Tone
Power on	Power on
Power off	Power off
Pairing Successfully	Connect
Volume up/down	"toot"
Battery Low	"toot" every 5 minutes
Mic Mute	"toot" every 3 seconds

Function Introduction:

1. Pair with 2 devices simultaneously

   M800BTD can pair with 2 devices simultaneously.

   1) Connect the first device with M800BTD
   2) Turn off the Bluetooth function of the first device
   3) Connect the second device with M800BTD
   4) Turn on the first device's Bluetooth function, then M800BT is paired with both devices.

2. Redial function

   Quick press the multi-function button twice to redial the last call.

3. One-touch play function

   Press the multi-function button once, the default music player of the mobile phone will play automatically (some mobile phones cannot implement this function).

4. Automatic re-connection function

   Bluetooth connection can be automatically re-connected even if disconnected within 5 minutes in the effective distance. If reconnect fails, please turn off the headset and turn it on again to reconnect.

5. Mic mute function

   Long press the plus button for 2 seconds to activate mic mute during a call, repress the plus button for 2 seconds to cancel mic mute. The tone "toot" will be heard every 3 seconds during mic mute status.

⚠️ Cautions:

1. Most mobile phones have headset power on screen display. When headset battery low, the headset will beep and the indicator will turn red. Please charge it in time.
2. Do not connect the charged headset to the charging circuit for a long time. Overcharging will shorten battery life.
3. Please keep the headset battery safely. Do not put the battery or the headset into fire or water to avoid explosion.
4. Do not use headset with high volume for extra long time, which may cause hearing loss. Always listen at a moderate level.
5. Do not connect the high voltage device to charge, which may cause damage to the headset.
6. Make sure that the headset is fully charged before using it if long time no use.
7. Lifetime of the battery will be significantly reduced if your device is left uncharged for a long time. We therefore recommend that you recharge your device at least once a year.

Product Warranty Card

Customer Name		Product Model No.	
Date of Purchase		Tel No./E-mail:	
Problem Description:			
Microphone	Speaker	Battery	Buttons
Warranty: Failure of headset buttons, speaker or microphone; charge unavailable. Out of Warranty: 1. Ear cushions broken. 2. Fail to follow the user manual or disassemble the headset. 3. Incorrect connect with high voltage device for charging which causes earphone damage. 4. Artificial damage caused by impact, falling, water, pulling.			
OQC CHECKING			