Fanvil

USB/Bluetooth　Speakerphone

User Manual

www.fanvil.com

Product introduction

USB/Bluetooth Speakerphone is an omni-directional microphone and a bluetooth speaker.

It is used as a high-quality microphone and speaker for online meeting and compatible with apps such as Zoom\Teams. Users can enjoy clear remote conference experience anytime, anywhere.

Product introduction

Accessories List

Speakerphone

Instructions

Data cable

Product introduction

Buttons and lighting instructions

📞 Phone Calls

Short press to answer/
hang up calls

Volume/power indicator

● means on   ○ means off

Volume indicator

● ● ● ● ● Maximum volume

○ ○ ○ ○ ○ Minimum volume
Power indicator (short press on power button)

● ● ● ● ● Power>80%

● ○ ○ ○ ○ Power≤20%

— Volume down

Short press to turn down the volume

+ Volume up

Short press to turn up the volume

🔇 Microphone

Short press to switch microphone status

Status Indicator
Red: Microphone mute
White: Microphone unmute

Buttons and lighting instructions

⏻ Power

Press and hold for 3 seconds to turn on or off the device

Status Indicator
Red light breathing: battery is below 10%
White light breathing: charging
White light on: battery full or not charging

*When the power is off and charging, the light goes off to indicate that it is full

✻ Bluetooth

Press and hold for 2 seconds to pair

Short press to disconnect Bluetooth

Status Indicator
Blue flashing: Bluetooth pairing

Blue on: Bluetooth connected

Instructions for use

1. Device connection

* Method 1: USB connection

• Connect the device to the computer via the supplied USB cable, and when you hear a hint tone, the connection is successful.

• Choose "Fanvil CS30" as the input/output audio device in system setting or in the online meeting software.

 * Method 2: Bluetooth connection

• Press the Bluetooth key for 2 seconds until the Bluetooth indicator flashes. Then open the phone or PC Bluetooth setting page, search the Bluetooth device "Fanvil CS30" for pairing; Click to connect.

• If you have an Android phone that supports NFC, turn on the NFC of the phone，and touch the device's NFC area to connect to Bluetooth.

Tip: The current version does not support OTG data cable directly connected to the phone

Instructions for use

2.Charging instructions

 * Charging

 • When using the   USB cable to connect to the computer, the device will enter
 the charging mode.

 • If   you   use   a   power   adapter   to   supply   power,   you   should
 purchase a power adapter that is FCC/CE certified and meets the requirements of
 the standard.

Tip: Before using the device for the first time, it is recommended that charge at least
1 hour to ensure sufficient power.

Instructions for use

Product name	AI Meeting Box
Product model	CS30
Product dimensions	112.5mm x 112.5mm x 35.4mm
Bluetooth	Bluetooth V5.1
Pickup radius	4 meters/13 ft
Microphone	4 omnidirectional microphone
Loudspeaker	5W
Battery capacity	2000mAh
Charging	5V—2A Type-C port

Frequently Asked Questions

Questions	8 Suggestions
The volume is not synchronized when the device is connected to the phone by Bluetooth	1.Confirm whether the phone supports Bluetooth sound synchronization, some Android phones do not support volume synchronization. 2.Some phone needs to open the volume setting permission in the system settings.
When the device is connected to the phone by Bluetooth, the ringtone of phone calls does not come out from the device	1.Check whether the phone volume is turned on, or the volume is too low. 2.Check whether the device can speak normally. 3.Choose audio input/output in the meeting software.
No sound when device is connected to Windows PC by Bluetooth	1.It is recommended that when playing music, select the speaker with the name "stereo" on your PC. 2.It is recommended to choose the speaker with the name "hand free" for the audio output speaker during the call or meeting.
No sound when the device is connected to FaceTime/ Zoom/Teams/Google Hangouts etc. by Bluetooth	1.Check whether the input /output of the call software are properly set to "Fanvil CS30". 2.Check whether the computer audio driver is normal, it is recommended to restart the computer and try again.
No response when the device is connected to the computer using USB	1.Check whether the device is connected to phone, please disconnect the connection first, and then use the cable to connect the device. 2.Check whether the USB data cable is damaged. 3.Reboot the device and try again.

Fanvil Technology Co., Ltd

Website: www.fanvil.com

EMail: sales@fanvil.com   support@fanvil.com

Tel: +86-755-2640-2199   **Fax:** +86-755-2640-2618

Add: 10/F Block A, Dualshine Global Science Innovation

Center, Honglang North 2nd Road, Bao'an District, Shenzhen,

China