

CONTROL FUNCTIONS

CE2 White/Black
LE2 White/Black
352 White / Black



Volume +



1 x Tap
Answer | Hang Up | Play | Pause
2 x Taps 3 x Taps
Next Song Previous Song



Volume -



CE1 White/Black
LE1 White/Black
351 White / Black



+ Volume Up

 
Single Click: Answer | Hang Up

 
Single Click: Play | Pause

 
Double Click: Skip Track
Triple Click: Previous track

- Volume Down


Siri | OK Google
Press for 3 Seconds